



Assembly Instructions for DYMU

Parts:

- A. Dolly base (1)
- B. Side tubular handles (2)
- C. Front tubular handle (1)
- D. Bolts (2)
- E. Lock nuts (2)

Tools needed: ratchet with ½" socket and pliers.

- 1. Open the carton and place base of dolly on the floor.
- 2. Take the two side handles from the carton and insert the sides with the holes through the sleeves of front handle.
- 3. Lift the front handle up until the holes of the sleeves match up with the holes on the side handles.
- 4. Insert the bolts into the holes and place nuts onto bolts.
- 5. Insert side handles into the six sleeves of the dolly base. Make sure front handle is at the end of the unit that has the swivel casters. Make sure to insert side handles as tightly as possible.
- 6. Using a ratchet and pliers tighten both bolts.

If you experience any problems with this product, please call our customer service department at 800-261-4112.