

ATTENTION: TO INSURE SAFE AND EASY USE OF YOUR WESCO APPLIANCE/
VENDING TRUCK, READ THESE INSTRUCTIONS BEFORE USING.

Description

The Wesco Aluminum Vending Machine Truck is specifically designed for transporting loads of up to 550 lbs. It features a lightweight aluminum frame with auto rewind ratchet, 6" moldon rubber wheels and a 24" wide by 5" deep nose plate.

This product is distributed by:

Wesco Industrial Products, LLC
1250 Welsh Road
North Wales, PA 19454
Tel: 215-699-7031 Fax: 215-699-3836

Contact the factory for parts information and ordering.
Visit us on the web at www.wescomfg.com

Unpacking

When unpacking the Wesco Product, check carefully for shipping damage and missing parts. If damage has occurred or any parts are missing, file a claim with the delivering carrier within 24 hours and notify the dealer from whom the unit was purchased.

Warranty Repairs

If the unit does not work properly, contact your dealer or the factory (215-699-7031) for units less than 90 days old.

Non-Warranty Service

If units are older than 90 days, repairs can be made easily on site with factory supplied parts.

NOTE: Do not send units to the factory for service without first obtaining a "Return Merchandise Authorization" (RMA) number from the customer service department. We will not be responsible for merchandise returned without proper authorization.

General Safety Information

The Wesco Aluminum Vending Machine Trucks are designed for specific functions. To insure proper use, the following instructions must be adhered to:

- (1) DO NOT overload the Truck beyond the rated capacity of the unit, Maximum capacity: 550 lbs
- (2) Check truck & all hardware for wear and tightness before use.
- (3) DO NOT use if nylon belt is worn or cut. Immediately remove unit from service and repair before use.
- (4) DO NOT allow belt to twist when securing load.
- (5) Firmly tighten belt around load before moving.
- (6) Use extreme caution when moving on uneven floors.
- (7) When using caster kickout, it must be in the fully extended position with the support bar in the lowest position before putting any weight on the casters.

Specifications

Part #	272410	272411	272412
Model Number	AAP-61	AAP-612	AVT-61
Capacity (lbs.)	550	550	550
Overall Width (in.)	24	24	24"
Overall Height (in.)	61	61	61
Overall Depth (in.)	12	12	12
Wheel (in.)	6 x 2	6 x 2	6 x 2
Caster (in.)	N/A	N/A	2 x 1
Weight (lbs.)	40	43	50



Figure 1
272410 (Single Ratchet)



Figure 2
272410 (Double Ratchet)



Figure 3
272412 (Vending)

ATTENTION: TO INSURE SAFE AND EASY USE OF YOUR WESCO APPLIANCE/
VENDING TRUCK, READ THESE INSTRUCTIONS BEFORE USING.

Operation

- (1) Slide nose plate under load, making sure load is fully seated on plate and against truck frame.
- (2) Unlock ratchet locking pawl.
- (3) Pull both ends of belt outward until there is enough to go around cargo.
- (4) Lock belt clasp together on far side of cargo.
- (5) Place pawl in locked position by pushing lever to the left so that it engages ratchet gear securely. Test by pulling on belt, making sure that it cannot be loosened further.
- (6) Using ratchet tighten belt to secure load. Be sure that pawl is in locked position so belt remains tight when ratchet handle is released.
- (7) To release load, pull ratchet to loosen pressure on pawl and unlock pawl. Belt is now free to be loosened.
- (8) Tilt back truck to balance load. Deploy rear caster assembly by pulling up on side caster carriage release while truck is tilted back (272412 vending truck only).

Spare Parts List

Item	P/N	Description	Qty.
1	150119	6 x 2 Wheel	2
2	108464	Rubber Channel	2
3	151247	4 x 1 Swivel Caster (For 272412 units Only)	2
4	150013	Stairclimber	2
5	052911	Complete Ratchet Assembly & Shaft	1
6	230050	Locking Pawl Assembly	1
7	053120	2-Piece Cargo Belt	1
8	108227	Vinyl Hand Grip	1
9	109688	Noseplate Rubber Padding	1
10	150118	Axle	1



Figure 4

(Pawl in Locked Position)



Figure 5

(Pawl in Unlocked Position)



Figure 6

(Closed Belt Clasp)



Figure 7

(Caster Carriage Release)




Figure 8

LIMITED WARRANTY

WESCO INDUSTRIAL PRODUCTS (WESCO) warrants to the purchaser of this product for a period of ninety (90) days from the date of purchase that this product shall be free of defects in material and/or workmanship, as follows:

1. WESCO will supply, at no charge, new or rebuilt replacements for any part that fails through a defect in material and/or workmanship during the warranty period. To obtain warranty service, you must deliver the product prepaid, to the WESCO factory.

2. This warranty does not cover any product or product part which has been subject to accident, misuse, abuse or negligence. WESCO shall only be liable under this warranty if the product is used the manner intended by the manufacturer as specified in the written instructions furnished with this product.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER. ANY EXPRESS WARRANTY NOT PROVIDED IN THIS WARRANTY DOCUMENT, AND ANY REMEDY FOR BREACH OF CONTRACT THAT, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION OR OPERATION OF LAW, IS HEREBY EXCLUDED AND DISCLAIMED. UNDER NO CIRCUMSTANCES SHALL WESCO BE LIABLE TO PURCHASER OR ANY OTHER PERSON FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER ARISING OUT OF BREACH OF WARRANTY, EXPRESS OR IMPLIED, A BREACH OF CONTRACT OR OTHERWISE. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY LIMITED IN DURATION TO THE DURATION OF THIS LIMITED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long any implied warranty lasts, so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.