
pro-line ii

92553 MANAGER'S CHAIR OPERATING INSTRUCTIONS



FEATURES

• PNEUMATIC SEAT HEIGHT ADJUSTMENT

To raise seat remove pressure from seat and lift lever (1) up. To lower seat height sit on chair and lift lever (1) up.

NOTE: It is normal for chair to slightly lower under body weight.

BACK TILT ADJUSTMENT

To tilt backrest, pull lever (1) out. To lock chair into position, push lever (1) in.

TILT TENSION ADJUSTMENT

To adjust title tension, Turn knob (2) clockwise to increase tension and counter-clockwise to decrease or ease the tension.

NOTE: Be careful not to completely loosen knob (2).

• ARM HEIGHT ADJUSTMENT

To adjust arm height, push button (3) in to allow the arms to move up or down freely. Release the button (3) once the desired height is reached.

WARNING

- 1. Use this product only one person at a time.
- Do not use this chair unless all bolts screws and knobs are securely tightened.
- Check that all bolts screws and knobs are tight every three months or as needed.
- 4. Do not overturn back tilt knob when decreasing tension.
- 5. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
- 6. Do not use chair as a stepladder.
- 7. Use this chair for its intended purpose only.
- 8. Use mild detergent only for cleaning.

PROLINE II LIMITED WARRANTY

ProLine II chairs are warranted from the date of purchase against failure due to material and workmanship as follows:

- Lifetime on component parts including pneumatic cylinder, control mechanism, base and casters.
- 3 Years on upholstery fabric and foam against wear and deterioration.
- Leather is not warranted against routine scratching and scuffing, as leather is subject to minor blemishes in use.

To make a warranty claim, contact Parts Department. Provide model number, proof of purchase, description of the problem and obtain return authorization. At it's option Office Star Products will:

- (a) Supply compatible components of current manufacture.
- (b) Repair the customer's component. The customer must prepay freight on any components returned to the factory. Return freight on components still in warranty will be paid by Office Star Products.

*All warranties are limited to the original purchaser for normal commercial usage defined as a standard forty hour work week by persons weighing 250 lbs. or less. The 54666 is for persons weighing 300 lbs. or less. The 39200, 39202, 39203, 81108, 81308 & 81608 are for persons weighing 400 lbs. or less. This warranty will not cover labor, freight or damage from misuse, abuse, negligence, alteration, accident, vandalism, rusting, acts of nature or any other event beyond the control of Office Star Products. The warranty does not cover cosmetic damage that may result from normal use. Liability for incidental or consequential damages is excluded. The user assumes all risk of injury resulting from use of this product. When usage is more than 40 hours per week, a five year warranty on all parts applies. Fabric is warranted for one year. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

All ProLine II chairs meet or exceed ANSI BIFMA standards.


It is the customer's responsibility to prepay freight on any components returned to the factory. Return freight on components covered by warranty will be paid by Office Star Products.

Our quality standards are among the highest in the industry. Sometimes, no matter how hard we try, there are times when parts are damaged or missing. Our Parts Department will do everything possible to promptly remedy the problem. Contact us via e-mail parts@officestar.net, by Fax 1-909-930-5629, or toll free parts number 1-800-950-7262, Monday through Friday 8:00 a.m. - 5:00 p.m. Pacific Time.





92553 MANAGER'S CHAIR ASSEMBLY INSTRUCTIONS



PART QTY
1. Base
2. Casters
3. Cylinder
4. Bellows
5. Mechanism
6. Seat Cushion
7. Backrest
8. Backrest Support Cover
9. Arms (9L & 9R)
10. Mechanism Screw
11. Backrest Screw
12. Back Support Screw w/ washer 3
13. Adjustment knob w/ washer 2
14. Backrest Cover Screw
15. Back Support (pre-installed) 1
16. Allen Wrench (not shown) 1

Remove all parts from carton, separate by part numbers indicated on parts list, and verify part quantities.

STEP 1 Insert five Casters (2) into Base (1), push hard until you feel or hear the Caster (2) snap into place. Insert Pneumatic Cylinder (3) into Base (1) and slip Belows (4) over Pneumatic Cylinder (3).

STEP 2 Attach Mechanism (5) to Seat Cushion (6) with the arrow towards the front of the chair using four Mechanism Screws (10).

FULLY TIGHTEN MECHANISM SCREWS (10).

STEP 3 Attach Arms (9L & 9R) to Seat Cushion (6) using two Adjustment knobs w/ washers (13) for each Arm (9).

FULLY TIGHTEN ADJUSTMENT KNOBS (13).

STEP 4 Attach Back Support (15) to rear of Seat Čushion (6) using three Back Support Screws w/ Washers (12). FULLY TIGHTEN BACK SUPPORT SCREWS (12). Secure Backrest (7) to Back Support (15) using one Backrest Screw (11). FULLY TIGHTEN BACKREST SCREW (11). Attach Backrest Support Cover (8) to Backrest (7) using two Backrest Cover Screws (14) as shown in Detail A. FULLY TIGHTEN BACKREST COVER SCREWS (14).

STEP 5 Place the assembled seat on top of Pneumatic Cylinder (3) and apply downward pressure.

ATTENTION: MAKE SURE ALL SCREWS ARE FULLY TIGHTENED BEFORE USING CHAIR.